

CORRECT APPLICATION OF HP10088 & HP10120 AIR SPRING KITS

Pacbrake has released air spring kits for 1988 to 2000 GMC/Chevrolet 1500, 2500 and 3500 trucks. It is important before ordering the kit to measure the clearance between the jounce bumper mounting plate on the frame to the jounce bumper contact pad on the axle.

This clearance is important to ensure the correct height of air spring is installed.

Vehicles with **less than** 7¼" between the jounce bumper mounting pad on the frame and the axle jounce bumper contact pad, must use a single convoluted air spring (Pacbrake kit HP10120).

Vehicles with **more than** 7¼" between the jounce bumper mounting pad on the frame and the axle jounce bumper contact pad, must use a double convoluted air spring (Pacbrake kit HP10088).

