

installation

PRESSURE SWITCH KITS HP10110 & HP10111

HP10110 kit includes C11578 pressure switch, 105 PSI/ON and 135 PSI/OFF

HP10111 kit includes C11560 pressure switch, 85 PSI/ON and 105 PSI/OFF

INSTALLATION

- 1 Using the fittings provided, install the pressure switch in a location for it to sense air tank pressure
- 2 Use thread sealant on all fittings to prevent air leaks. Air leaks will shorten the life of the air compressor
- 3 Using the provided electrical connectors, connect one side of the pressure switch to pin 85 of the Pacbrake relay and connect the other side to a good chassis ground.

